


KICK Decagon 55"


(Brown/Black)

10 IN 1 MULTI-GAME FOOBALL TABLE ASSEMBLY INSTRUCTIONS



FY510

WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE









Email:

IF YOUR TABLE HAS DAMAGES, MISSING PARTS, OR YOU ARE NOT 100% SATISFIED PLEASE CONTACT KICK, NOT THE RESELLER.

- SCAN THIS QR CODE TO CONTACT US IF YOU FACE ANY ISSUES.

FOR THE LATEST INSTRUCTION MANUALS, VIDEOS, TABLE ASSEMBLY INFO, DIFFERENT GOALIE SETUPS, PLAYER TYPES, AND OTHER HELPFUL TIPS - PLEASE VISIT THE LINK BELOW OR SCAN THIS QR CODE-



www.KICKFoosballTables.com/Instructions/

CONTACT INFORMATION:

Support@KICKFoosballTables.com Website: www.KICKFoosballTables.com

Phone: 1 (866) 844-KICK (5425) or (210) 664-8934 **MAILING ADDRESS:**

KICK Sports PO Box 790311


San Antonio, Texas 78279


PARTS LIST

					<u> </u>	
1	2	3	4	5	6	7
000						
X2	X2	X_1				
SIDE PANEL	END PANEL	TABLE TENNIS	PLAYFIELD X1	X2 RIGHT LEG	LEFT LEG	BILLIARD TABLE
8	9	HOCKEY 10	11	12	13	14
				\}{\(\)		
	хз			())	(۱)	
X3		X2	X2		X1	X6
SUPPORT BRACE	SUPPORT ROD	PUCK	STRIKER	BOWLING PIN SET	BOWLING BALL	PUCKS
15	16	1a ॄ	1b ှ	2a	2b	3a
	X4	×2	×2	x2	×2	X2
BALL ENTRY CUP	STOP RING	TRIANGLE a	TRIANGLE b	L STYLE PLASTIC a	L STYLE PLASTIC b	LONG PLASTIC a
3b	P13 1 SET	18	19	20	21	22a
3	000000000		\sim			
	000000000000000000000000000000000000000	×8	\bigvee_{x}	X16	X16	
X2	SCREW HOLE CAP					X13
LONG PLASTIC b	(to cover the hole of the screws S1)	ROD HANDLE	ROD END CAP	ROD BUMPER	ROD WASHER	PLAYER
22b	22c	22d	23	24	25	26a
🦚						
₩ ×13	X13	X13	X4	X2	X2	X2
PLAYER	PLAYER	PLAYER	3 PLAYER ROD	2 PLAYER ROD	5 PLAYER ROD	SOCCER BALL
26b	26c	27	28	29	30	31
		0000				
		0000				
X2	X2	0000 _{x1}	X1	X2	X1	X2
SOCCER BALL	SOCCER BALL	BILLIARD BALLS SET	TRIANGLE	CUC STICK	BRUSH	CHALKS
32	33	34	46	47	48	49
6				(I)		
X2			X2 >	X1	X1	_{X2}
(Pre-installed) HOCKEY GOAL	X2 GOAL BOX TOP	X2 GOAL BOX BOTTOM	LEG CROSS ROD	SHUFFLEBOARD /BOWLING TOP	TABLE TENNIS NET	TABLE TENNIS POSTS
50	51	52	53	54 🕙	55	56
						1
) x2	X2	X2				
	TABLE TENNIS	PUSH HOCKEY STICK	X1SET	X1SET	X1SET	X4
TABLE TENNIS BALL	PADDLE	FUSH HUCKEY STICK	BACKGAMMON SET	CHESS SET	DICE SET	LEG LEVELER
H2	H4					
	•					
X1	X1					
ACCESSORY PANEL	ACCESSORY HOLDER					
	•			•	•	

WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


HARDWARE







WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE

STEP 2






WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 5A

Steps 5A to 5E are optional if you want.




STEP 5B

Attach the plastic 2a, 2b, 3a, 3b to the playing field with S1.




STEP 5C

Cover the Screw Hole Cap P13 to the screw hole.




STEP 5D



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 5E



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 6A

Steps 6A to 6E are optional if you want.




STEP 6B

Attach the plastic 1a, 1b, 3a, 3b to the playing field with S1.




STEP 6C

Cover the Screw Hole Cap P13 to the screw hole.




STEP 6D




WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 6E




WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE




WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE

