


KICK Dyad 55"

(Brown/Black)

2 IN 1 MULTI-GAME SWIVEL FOOSBALL TABLE ASSEMBLY INSTRUCTIONS



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE







Official Website of KICK Foosball Tables

IF YOUR TABLE HAS DAMAGES, MISSING PARTS, OR YOU ARE NOT 100%
SATISFIED PLEASE CONTACT KICK, NOT THE RESELLER.

SCAN THIS QR CODE TO CONTACT US IF YOU FACE ANY ISSUES.

FOR THE LATEST INSTRUCTION MANUALS, VIDEOS, TABLE ASSEMBLY INFO, DIFFERENT GOALIE SETUPS, PLAYER TYPES, AND OTHER HELPFUL TIPS - PLEASE VISIT THE LINK BELOW OR SCAN THIS QR CODE————



www.KICKFoosballTables.com/Instructions/

CONTACT INFORMATION:

Email: Support@KICKFoosballTables.com Website: www.KICKFoosballTables.com

Phone: 1 (866) 844-KICK (5425) or (210) 664-8934

MAILING ADDRESS:

KICK Sports PO Box 790311

San Antonio, Texas 78279

PARTS LIST


	1	r	r	r		1	
1	2	3	4	5	6	7	
				[···			
المعتقدة الم		~~~					
X2	X2	X1	X2	X2]	X2	X1	
SIDE PANEL	END PANEL	PLAYFIELD	LEG PANEL	RIGHT LEG	LEFT LEG	BILLIARD TABLE	
8	9	10	11	12	13	14	
X2	хз	Х3	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		
		•	X2	X2	X2	X2	
SUPPORT BRACE	SUPPORT BRACE	SUPPORT ROD	ACCESSORY HOLDER BOARD	SIDE LEG PANEL	END LEG SUPPORT PANEL	END TOP RAIL	
15	16	1a	1b	2a	2b	3a	
15A-2PCS 15B-2PCS							
🕻							
₩ X4	X2	V X2	V X2	□ X2	X2	X2	
BALL RETURN SUPPORT BOARD		TRIANGLE a	TRIANGLE b	L STYLE PLASTIC a	L STYLE PLASTIC b	LONG PLASTIC a	
3b	P13 1 SET	18	19	20	21	22a	
3	0000000000			0		🥝	
6	0000000000	X8	X8	X16	X16	X13	
LONG PLASTIC b	SCREW HOLE CAP (to cover the hole of the screws S1)	DOD HANDLE	DOD END OAD	DOD DUMBED			
I TOMO I LAGINOD	(to cover the note of the sciews 31)	ROD HANDLE	ROD END CAP	ROD BUMPER	ROD WASHER	PLAYER	
22b	22c	22d	25	26	ROD WASHER 27	PLAYER 28	
						28	
22b	22c	22d	25	26	27		
22b	22c	22d X13	25 X4	26 X2	27 X2	28 X2	
22b X13 PLAYER	22c X13	22d X13	25 X4 3 PLAYER ROD	26 X2 2 PLAYER ROD	27 X2 5 PLAYER ROD	28 CUC STICK X2	
22b X13 PLAYER	22c X13	22d X13	25 X4 3 PLAYER ROD	26 X2 2 PLAYER ROD	27 X2 5 PLAYER ROD	28 CUC STICK X2	
22b X13 PLAYER	22c X13	22d X13	25 X4 3 PLAYER ROD	26 X2 2 PLAYER ROD	27 X2 5 PLAYER ROD	28 CUC STICK X2	
22b X13 PLAYER 29a	22c X13 PLAYER 29b	22d X13 PLAYER 29c	25 X4 3 PLAYER ROD 30	26 X2 2 PLAYER ROD 31	27 X2 5 PLAYER ROD 32	28 CUC STICK X2 CUC STICK	
22b X13 PLAYER 29a X2	22c X13 PLAYER 29b X2	22d X13 PLAYER 29c X2	25 X4 3 PLAYER ROD 30 X2	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38	27 X2 5 PLAYER ROD 32 X4	28 CUC STICK X2 33	
22b X13 PLAYER 29a X2 SOCCER BALL	22c X13 PLAYER 29b X2 SOCCER BALL	22d X13 PLAYER 29c X2 SOCCER BALL	25 X4 3 PLAYER ROD 30 X2 ROTATION AXIS	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER	27 X2 5 PLAYER ROD 32 X4 LOCKER	28 CUC STICK 33 X2 MANUAL SCORER	
22b X13 PLAYER 29a X2 SOCCER BALL 34	22c X13 PLAYER 29b X2 SOCCER BALL 35	22d X13 PLAYER 29c X2 SOCCER BALL	X4 3 PLAYER ROD 30 X2 ROTATION AXIS	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000	27 X2 5 PLAYER ROD 32 X4 LOCKER	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34	22c X13 PLAYER 29b X2 SOCCER BALL 35	22d X13 PLAYER 29c X2 SOCCER BALL 36	X4 3 PLAYER ROD 30 X2 ROTATION AXIS	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 0000 X1	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34 CORNER POCKET LID	22c X13 PLAYER 29b X2 SOCCER BALL 35 X2 SIDE POCKET LID	22d X13 PLAYER 29c X2 SOCCER BALL 36 X2 SOCCER GOAL	25 X4 3 PLAYER ROD 30 X2 ROTATION AXIS 37 X4 SPACER BLOCK	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 X1 BILLIARD BALLS SET	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34	22c X13 PLAYER 29b X2 SOCCER BALL 35	22d X13 PLAYER 29c X2 SOCCER BALL 36	X4 3 PLAYER ROD 30 X2 ROTATION AXIS	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 0000 X1	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34 CORNER POCKET LID	22c X13 PLAYER 29b X2 SOCCER BALL 35 X2 SIDE POCKET LID	22d X13 PLAYER 29c X2 SOCCER BALL 36 X2 SOCCER GOAL	25 X4 3 PLAYER ROD 30 X2 ROTATION AXIS 37 X4 SPACER BLOCK	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 X1 BILLIARD BALLS SET	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34 CORNER POCKET LID 41	22c X13 PLAYER 29b X2 SOCCER BALL 35 X2 SIDE POCKET LID	22d X13 PLAYER 29c X2 SOCCER BALL 36 X2 SOCCER GOAL	X4 3 PLAYER ROD 30 X2 ROTATION AXIS 37 X4 SPACER BLOCK	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 X1 BILLIARD BALLS SET	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	
22b X13 PLAYER 29a X2 SOCCER BALL 34 CORNER POCKET LID	22c X13 PLAYER 29b X2 SOCCER BALL 35 X2 SIDE POCKET LID	22d X13 PLAYER 29c X2 SOCCER BALL 36 X2 SOCCER GOAL	25 X4 3 PLAYER ROD 30 X2 ROTATION AXIS 37 X4 SPACER BLOCK	26 X2 2 PLAYER ROD 31 X8 PLAYER ROD STOPPER 38 0000 0000 0000 X1 BILLIARD BALLS SET	27 X2 5 PLAYER ROD 32 X4 LOCKER 39	28 CUC STICK 33 X2 MANUAL SCORER 40	


HARDWARE


44	X20	45	X24	46a	X26	46b	X26	47a	X26	47b	X26	48	X12	
@	Opening Opening		China		Opposition .							Ottities		
1/4" x	2" BOLT	1/4" x 1-1	1/4" BOLT	5/32" x1-1	'8" BOLT	5/32" x1-1/8" BOLT		5/32" NUT		5/32" NUT		1/8" x1/2" SCREWS		
49	X8	50	X8	51	X12	52	X6	53	X56	54	X4	55	X24	
6	Jamas			Other		©			0				Ototos	
5/32" :	5/32" x 1" BOLT 5/32" NUT		" NUT	1/8" x1-3/8" SCREWS		1/4" NUT		1/	1/4" WASHER		M6 NUT		1/8" x1" SCREWS	
56	X24	57	X8	58	X2	59	X8	60	60 X8			63		
85	De la companya della companya della companya de la companya della	Q					OTTO		Olita		(X8)	Ø	NA X4	
1/8" x1-1/2	2" SCREWS	REWS 1/8" x1/2 " SCREWS		ALLEN WRENCH		1/8" x2-1/4" SCREWS		1/8" x /8"SGREWS		1/4" NUT		1/8" x1-1/4" SCREWS		
S1	X36													
85	TT													
1/2"FLAT H	EAD SCREWS													

Assembly Instructions

STEP 1 Attach the 2 SOCCER GOALS (#36) to the both ends of the Play Field (#3)










WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 4








STEP 7 In this step please pay attenion the orientation and the position for the BALL RETURN BOTTOM BOARD (#16)






WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 10A

Steps 10A to 10E are optional if you want.




STEP 10B

Attach the plastic 2a, 2b, 3a, 3b to the playing field with S1.




STEP 10C


Cover the Screw Hole Cap P13 to the screw hole.




STEP 10D



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE




Insert the rod end part way through one side panel, and then place the rest of the parts needed on each rod, in the order shown, before inserting through the other side panel.



WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE


STEP 11A

Steps 11A to 11E are optional if you want.




STEP 11B

Attach the plastic 1a, 1b, 3a, 3b to the playing field with S1.





STEP 11C

Cover the Screw Hole Cap P13 to the screw hole.




STEP 11D






WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE

STEP 12





KICKFoosballTables.com | (866)-844-KICK (5425) | support@kickfoosballtables.com

WARNING: TWO ADULTS ARE NEEDED TO ASSEMBLE THE SOCCER TABLE

STEP 14

